

PRISM KIT

FUNAI / SYMPHONIC / MAGNAVOX

PHILCO / SYLVANIA / PHILIPS

WHITE-WESTINGHOUSE / SEARS

HITACHI

PART NO: MBK-67-SENS



SYMPTOMS: SHUTSDOWN & EJECTS TAPE IN PLAY OR RECORD, OR GOES TO STOP MODE AFTER 10-15 SECONDS. ALSO, MAY TRY TO LOAD CASSETTE TRAY WITHOUT CASSETTE BEING PRESENT.

MODELS: FUNAI: FE226G, FE426G, FE436G, FV206G, FV4261G, F9TGG1, F13TRG1, F19TRG1

SYMPHONIC: SE226G, SE426G, SE436G, SE456G, SV206G, SV4261G, TVCR9G1, TVCR13G1, TVCR19G1

MAGNAVOX/PHILIPS/SYLVANIA/PHILCO: VRU222, VRU242, VRU262, VRU340, VRU342, VRU344, VRU362, VRU364, VRU422, VRU542, VRX222, VRX242, VRX262, VRX360, VRX364, P962VR, P964VR, P966VR, L9TRG, L13TRG, L19TRG

HITACHI: VT-MX421A, 13VR3B, 20VR4B

WHITE WESTINGHOUSE: WW827

SEARS: 1995-1997 MODELS

LOCATION/REF #	PART NUMBER	DESCRIPTION
74	OVM302723 / TE12366	PRISM
D511	QPQSSLR938CV	CENTER LED EMITTER
Q503	ST-316R2-B / PT380F	END SENSOR
Q504	ST-316R2-B / PT380F	START SENSOR

SPECIAL INSTRUCTIONS:

- REF #74 (PRISM) IS LOCATED ON MECHANICAL DECK
- D511, Q503 & Q504 ARE LOCATED ON MAIN PC BOARD.
- **NOTE: PC BOARD IS MARKED WITH ORIENTATION OF Q503 AND Q504. INSTALL WITH THE LONGER LEG AS SHOWN ON THE PC BOARD.**
- **NOTE POLARITY OF D511 (LED) AND INSTALL NEW LED IN THE SAME ORIENTATION.**
- **IF ANY OF THESE COMPONENTS ARE REVERSED, THE VCR WILL NOT OPERATE PROPERLY**