


BIAS-EASY QUICK-START INSTRUCTIONS

Step One

Insert tubes into Bias-Easy Adapters, and the adapters into the amp's tube sockets. Important: Make sure you have a speaker connected to the amplifier! Tube amps can fail if powered on without a speaker!



Step Two

Turn the amp's power on, and let the tubes warm up as you would if you were turning your amp on to play.



Step Three

BIAS-EASY QUICK-START INSTRUCTIONS PAGE 2

Once the tubes have warmed up, switch the standby off so the amp is in operating mode. The Bias-Easy will show you the tube's idle current (bias) in milliamps (mA).



Step Four

Using the bias adjustment trim pot in your amp, usually located inside the chassis or underneath it, adjust the tubes' bias current to the desired level. Switching between the sockets will show each tube's current on the meter.



Revisit Products
Studio Sound Electronics
Clearwater, Florida USA
www.amprepairparts.com